

# EscaTeq Tampone tipo W - 6 Pz - cm. 60

**Codice del prodotto:** EQ801025  
**Disponibilità:** 6

**Prezzo:** € 260,01

**Tax Ex:** € 213,12

## Short Description

Tampone per il lavaggio manuale delle scale mobili

## Descrizione

**TAMPONE tipo "W"**  
**per usarlo serve il Telaio Esca Teq**

### **Pulisce la scala mobile in pochi minuti**

Esca-Teq economico sistema per pulire la scala o il tappeto mobile.

### **VANTAGGI:**

- una sola persona operativa
- non è necessario fermare la scala mobile
- nessuna fonte di alimentazione esterna
- il design leggero lo rende facile da trasportare e semplice da immagazzinare
- l'ingegnoso tampone in schiuma pulisce le macchie più difficili in modo delicato ed efficace
- il tampone può essere lavato e riutilizzato per almeno 10 volte.

### **SCEGLI IL TAMPONE GIUSTO** a seconda della larghezza della tua scala mobile:

Tamponi disponibili da cm. 60 - cm. 80 - cm. 100.

[Depli ant](#)

[Domande frequenti](#)

[youtube url="https://www.youtube.com/watch?v=PeTJpVWY1hc"]

## Accessori complementari

### Accessori complementari:

- Telaio Esca Teq da cm. 60
- Clean-Teq detergente speciale appositamente formulato per i tamponi Escq Teq.
- Jerrycan tanica vuota per corretto dosaggio del prodotto Clean-Teq.
- Fit Card - dima per verificare le scanalature della scala mobile in "V" o "W".

## ISTRUZIONI PER L'USO

ESCATEQ  
 escalator cleaning tools
 ESCALATORS GET DIRTY,  
ESCA TEQ MAKES CLEANING THEM EASY

1



Block the running escalator opposite to the side you are cleaning.

2



Mix solution 10 parts water, to 1 part Clean-TEQ.

3



Pour the diluted solution into the trough. Do not overfill!

4



Mount pad to device.

5



Allow the cleaning pad to absorb the solution.

6



Place the device onto the moving treads, allow it to align with the combs and drop into place.

7



Tilt the device back and then forward, to help it align with the tread groves.

8



Hold the device in place with light downward pressure.

9



Remove the dirty pad carefully.

10



Rinse pads using moderate water pressure.

11



Replace pads when they become damaged or worn.

12



Dry & re-use pads.

ESCALATOR  
CLEANING  
FREQUENCY

Traffic	Location	Recommendation
↑↑↑ HIGH	Airports & Subways	Daily
↑↑ MEDIUM	Shopping Malls & Casinos	Bi-Weekly (twice a week)
↑ LOW	Hotels & Office Buildings	Weekly

Important: Keep fingers, loose clothing, shoe laces, hair, jewelry etc. away from the device and the escalator treads during use. Do not stand or step on the device while it is in operation. The escalator must be dry before allowing passengers back on.

Visit [escateq.com](http://escateq.com) for more information or email us at [info@escateq.com](mailto:info@escateq.com) Copyright 2019 ESCATEQ BY. All rights reserved

## VEDI COSTO DI UTILIZZO

**Cleaning your escalators over 100 times per year with Tread-TEQ can cost less than having them cleaned once a year by an outsourced escalator cleaning company!**

	<b>Once a week</b> 52 cleanings per year	<b>Twice a week</b> 104 cleanings per year	<b>Every day</b> 365 cleanings per year
<b>Cost per Cleaning</b>	€ 9.21	€ 7.39	€ 5.99
<b>Annual Cost</b>	€ 478.92	€ 768.56	€ 2,186.35

IMPORTANT: See calculations and disclaimer page for more details. Calculations portrayed are all estimates. An outsourced annual restorative cleaning cost of €1200.00 was used for this comparison, your costs may vary. Estimates portrayed are based on a 1000mm escalator. 800mm and 600mm escalators will cost less.

## Product Gallery

